



# Asus G73JH-RBBX05 Hard Drive Replacement

This guide will help you locate and remove the hard drive on your Asus G73JH-RBBX05.

Written By: Trevor Sprosty



## INTRODUCTION

Locate and remove your hard drive for replacement or upgrade.

---



### TOOLS:

- [iFixit Opening Tools](#) (1)
  - [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — Hard Drive



- Flip the laptop over and remove the two 4mm screws located at the bottom of the laptop with the PH0 screwdriver.

## Step 2



- Using a plastic opening tool or finger, remove the access panel.
- ⓘ Apply constant force until the panel releases from the clips underneath.



### Step 3



- Locate the two, 4mm screws on the hard drive. Remove them with the PH0 screwdriver.

### Step 4



- Using the black tab located on the hard drive, pull out the hard drive.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 04:32:30 AM.